

Well Intervention Pressure ControlAbbreviations used in this document

kPa	=	KiloPascal (pressure)
kPa/m	=	KiloPascal per metre
BHP	=	Bottom Hole Pressure
kg/m ³	=	Kilogram per cubic metre
m ³ /m	=	Cubic metres per metre
m ³ /min	=	Cubic metre per minute
m ³ /stroke	=	Cubic metre per stroke
M	=	Metre
MD	=	Measured Depth
TVD	=	True Vertical Depth
SIWHP	=	Shut in Well Head Pressure
0.00981	=	Constant factor

1. PRESSURE GRADIENT (kPa/m)

$$\text{Mud Density (kg/m}^3\text{)} \times 0.00981$$

2. FLUID DENSITY (kg/m³)

$$\text{Pressure (kPa)} \div \text{TVD (m)} \div 0.00981$$

Or

$$\frac{\text{Pressure (kPa)}}{\text{TVD (m)} \times 0.00981}$$

3. HYDROSTATIC PRESSURE (kPa)

$$\text{Mud Density (kg/m}^3\text{)} \times 0.00981 \times \text{TVD (m)}$$

4. FORMATION PRESSURE (kPa)

$$\text{Hydrostatic Pressure in Drill String (kPa)} + \text{SIDPP (kPa)}$$

**5. TOTAL PRESSURE AT A GIVEN DEPTH IN A SHUT IN WELLBORE (kPa)
(Where BHP = Formation Pressure)**

$$\text{Hydrostatic pressure of Gas (kPa)} + \text{Hydrostatic Pressure of Oil (kPa)} + \text{SIWHP (kPa)}$$

6. TIME TO PUMP (minutes)

a. Tubing
$$\frac{\text{Tubing Capacity (m}^3\text{/m)} \times \text{MD (m)}}{\text{Pump Rate (m}^3\text{/min)}}$$

b. Annulus
$$\frac{\text{Annulus Capacity (m}^3\text{/m)} \times \text{MD (m)}}{\text{Pump Rate (m}^3\text{/min)}}$$



7. STROKES TO DISPLACE (Strokes)

- a. Tubing** $\frac{\text{Tubing Capacity (m}^3/\text{m)} \times \text{MD (m)}}{\text{Pump Displacement (m}^3/\text{stroke)}}$
- b. Annulus** $\frac{\text{Annulus Capacity (m}^3/\text{m)} \times \text{MD (m)}}{\text{Pump Displacement (m}^3/\text{stroke)}}$